



## Step 1

Mark the hole locations by aligning the wire rack to the wall



## Step 2

Drill the areas you marked.



## Step 3

Install the dowels.



## Step 4

Screw the wooden shelves into the screw slots on the wire



## Step 5

Hang the rack you prepared into the wall dowels by screwing.